Urban RFI and Ham Radio



Wyatt Technical Services LLC Woodland Park, CO Contact via: <u>www.emc-seminars.com</u>



2021 JOINT IEEE INTERNATIONAL SYMPOSIUM ON ELECTROMAGNETIC COMPATIBILITY, SIGNAL & POWER INTEGRITY & EMC EUROPE 60 min WWW.emc2021.org • #IEEE_ESP21

Kenneth Wyatt – WA6TTY (1973)

Aerospace – 10 years HP/Agilent – 21 years EMC Consulting – 12 years

Author: EMI Troubleshooting Cookbook EMC Pocket Guide RFI Pocket Guide (ARRL) EMC Troubleshooting Kit – Vol 1 Troubleshooting Emissions – Vol 2 (June 2021) Troubleshooting Immunity – Vol 3 (Sep 2021)





2021 JOINT IÉEE INTERNATIONAL SYMPOSIUM ON ELECTROMAGNETIC COMPATIBILITY, SIGNAL & POWER INTEGRITY & EMC EUROPE

www.emc2021.org •

Introduction

Urban RFI sources have increased to the point where it's an issue for HF and (even) VHF operators

- Large increase in noise floor over 25 years
- I see S7 to S9 (urban) and S0 (rural)
- Switch-mode power supplies
- Lighting, appliances, power supplies/modules
- Easy to see on waterfall displays
- Some mitigations



2021 JOINT IEEE INTERNATIONAL SYMPOSIUM ON ELECTROMAGNETIC COMPATIBILITY, SIGNAL & POWER INTEGRITY & EMC EUROPE
WWW.EMC2021.Org • #IEEE_ESP21

Types of Noise

Generally, three dominant sources:

- Impulse defective equipment in the mains or lightning (typically affects up through 7 MHz)
- Electronically-generated (dominant now) digital bus, VF motor drives, SMPS, solar controllers, wall warts, LED/CFL lighting, kitchen appliances (Major issue today!)
- Signal Leakage VDSL modem, CATV cable, etc.




DC-DC (switch mode) converters are everywhere

Lighting, electronic products, appliances, etc.

Most products today use switch-mode power supplies for energy efficiency.

AC Supplies: The mains voltage is rectified and filtered to about 300 VDC and then switched on and off at 50 to 500 kHz, then transformed down and filtered to the desired secondary voltages.

DC Supplies: The DC input is directly switched and either boosted or reduced and filtered to the desired voltages. Switch frequency 1 to 3 MHz.



#IEEE_ESP21

•



Faster rise/fall times generate higher harmonics


The risetime and fall times contain all the harmonic energy.


The faster the switched waveform, the higher the harmonic content.

Most SMPS switch in ms or ns.


Effective bandwidth of the energy is equal to BW (GHz) = 0.35 / Risetime (ns).

Example: a 1 ns risetime has an effective bandwidth of 350 MHz of harmonic content.











2021 JOINT LEEE INTERNATIONAL SYMPOSIUM ON ELECTROMAGNETIC COMPATIBILITY, SIGNAL & POWER INTEGRITY & EMC EUROPE

www.emc2021.org

60 Hz power line noise signature

Power line time domain signature of 120 Hz (or pulse intervals of 8.3 ms).

60 Hz sine wave crosses zero twice per cycle.

Example (QST, Sept 2021):

Set the receiver to AM at 6 kHz BW and set the oscilloscope to sync at line frequency at 2 ms/div.

Connect to the audio output.

RFI can occur from HF into the VHF bands




Figure 1 — The oscilloscope display of the power line noise signature at the audio output of IC-7700 receiver, 2 ms/div.

Source QST, Sept 2021, Page 35.



2021 JOINT IEEE INTERNATIONAL SYMPOSIUM ON ELECTROMAGNETIC COMPATIBILITY, SIGNAL & POWER INTEGRITY & EMC EUROPE
WWW.emc2021.org • #IEEE_ESP21

Typical SMPS time domain pulses


Switch mode power supplies (SMPS) typically switch at:

Mains powered: 10 to 500 kHz

On-board DC-DC: 100 kHz to 3 MHz

The example is an on-board DC-DC converter switching at 1 MHz. We're comparing inductive coupling using an H-field probe versus a conventional scope probe.

RFI can occur through 1 GHz. Harmonic spikes will occur every 2X the switch frequency.






Bus/clock noise for a typical digital product

EMI measured from a typical digital product using a near-field probe. The onboard noise spectrum from 1 to 1500 MHz shows:

- Yellow = Ambient noise floor
- Aqua = Ethernet clock
- Violet = On-board DC-DC converter

This self-generated EMI can affect cellular phone and GPS bands (circled).

https://www.edn.com/platform-interference/






Power Line RFI

This is a measurement of my own power line EMI, as measured from 100 kHz to 100 MHz. I was testing some power line filters for an article.

- Yellow = Ambient noise floor
- Violet = Raw line EMI
- Blue = Solar 7032-1 isolation transformer
- Green = OnFILTER AFN515FG filter




https://www.edn.com/review-tool-measures-power-line-emi/




www.emc2021.org • #I

2021 JOINT IEEE INTERNATIONAL SYMPOSIUM ON ELECTROMAGNETIC COMPATIBILITY, SIGNAL & POWER INTEGRITY & EMC EUROPE

Example: Wall wart RFI




RFI from a typical DC-DC converter IC



Yellow = ambient, Violet = differential mode, Aqua = common mode



Effect of ringing




- Switch-mode power supplies, DC-DC converters and AC/DC inverters typically have ringing associated with the switched waveforms
- Ringing on a switched waveform will cause a resonance in the spectral emissions



Measuring switched-mode power supply ringing

- A Rohde & Schwarz RTE 1104 oscilloscope and RT-ZS20 (1.5 GHz) HF probe was used
- An H-field probe held close to the switching inductor may also be used
- Line up cursors on adjacent peaks to read off the ring frequency




https://www.edn.com/gan-technology-and-the-potential-for-emi/



www.emc2021.org •

2021 JOINT IEEE INTERNATIONAL SYMPOSIUM ON ELECTROMAGNETIC COMPATIBILITY, SIGNAL & POWER INTEGRITY & EMC EUROPE


Ringing causes peaks in the emissions



- 1 MHz GaN switcher with 300-500 ps rise time and a 217 MHz ring frequency creates broadband EMI as high as 800 MHz with peaks at 217 and 434 MHz as measured with Fischer F-33-1 current probe
- Yellow = ambient measurement, Aqua=input current, Violet=load current




LED/CFL lighting RFI tests





Several LED and CFL bulbs were tested for conducted emissions in the range 150 kHz to 30 MHz at 9 kHz RBW

EMIE N SIPIN GLASGOW




LED lighting conducted RFI tests (2010 vintage)

Yellow = ambient noise floor, Violet = Line, Blue = Neutral (Measured from 150 kHz to 30 MHz)

A sampling of several LED and CFL bulbs tested. The CFL looked similar to the "Good" example and the switching noise tapered off above 1 MHz. Bulbs were tested using "peak" detection, as that's similar to what you'll hear in the receiver.



LED lighting conducted RFI tests (2021 vintage)



A sampling of several more recent LED bulbs tested. Bulbs were tested using "peak" detection, as that's similar to what you'll hear in the receiver.



2021 JOINT IEEE INTERNATIONAL SYMPOSIUM ON ELECTROMAGNETIC COMPATIBILITY, SIGNAL & POWER INTEGRITY & EMC EUROPE **#IEEE_ESP21**

www.emc2021.org

Filtering techniques

- Good ferrite types for HF: (Fair-Rite 31, 43, 75 material)
- Clamp-on ferrites don't work well at HF, best to use toroid cores
- Powdered iron (hi-Q) is only good for RF power transfer don't use
- Commercial line filters
- Filtering the transmission line and antenna




Fair-Rite "Smart Home"

<u>Inside</u>

- Laptop Charger: <u>Planar Cores</u>
- Lighting and Light Fixtures: <u>Round Cable Snap-its</u>
 - Thermostat: <u>Chip Beads</u>
 - Washer/Dryer: <u>Toroids</u>
 - Smart TV: <u>Rods</u>
 - Refrigerator: <u>Flat Cable Cores</u>

<u>Outside</u>

- Air Conditioner Units: <u>Wound Beads</u>
- PV Solar Panels: *Flat Cable Snap-its*
 - Wind Turbines: <u>E-Cores</u>



At least one ferrite company has attempted to address RFI in the residential home environment. <u>https://www.fair-rite.com/animate/#smart_home</u>



Commercial line filters



Filter body MUST be bonded to chassis and located near the mains input for common mode filtering.



Example: An alternative to line filters



Appliance filter adapter - Bifilar-wound on 2.8 OD #75 core



Close-up (3 turns)

Courtesy, Dave Eckhardt (WOLEV)




2021 JOINT IEEE INTERNATIONAL SYMPOSIUM ON ELECTROMAGNETIC COMPATIBILITY, SIGNAL & POWER INTEGRITY & EMC EUROPE

 www.emc2021.org
 •
 #IEEE_ESP21

Filtering antenna EMI with common mode chokes

Ref: Fair-Rite Corp.





NTIEEE INTERNATIONAL SYMPOSIUM ON ELECTROMAGNETIC COMPATIBILITY, SIGNAL & POWER INTEGRITY & EMC EUROP
WWW.EMC2021.0rg • #IEEE_ESP21

Using a single common mode choke at transmitter

Test Conditions:

Data taken using an ICOM 7300, with 450-long doublet fed with parallel wire transmission line and antenna tuner set to 1:1 match.

A single common-mode choke (CMC) was used between the tuner and feed line. A second CMC at the antenna feed should also show some improvement.

Courtesy, Dave Eckhardt (WOLEV)







 S8.5 noise floor / many signals hidden

Examples of bifilar-wound common

S5.5 noise floor / many weaker signals readable

9 dB reduction in noise floor (based on the uncommon, but verified 3 dB/S-unit for ICOM 7300)

2021 JOINT IEEE INTERNATIONAL SYMPOSIUM ON ELECTROMAGNETIC COMPATIBILITY, SIGNAL & POWER INTEGRITY & EMC EUROPE

www.emc2021.org •

An different example of a CM filter for antennas

Frequency (MHz)	Measured CM Z (Ohms)
3.75	3.8k
7.15	3.8k
10.1	3.2k
14.2	2.5k
18.1	2.0k
21.25	1.7k
24.1	1.5k
28.4	1.2k
50	680



- Uses doubled #31 cores with 3T RG142 coax, each
- W1HIS design
- Kit available from www.kf7p.com



2021 JOINT IEEE INTERNATIONAL SYMPOSIUM ON ELECTROMAGNETIC COMPATIBILITY, SIGNAL & POWER INTEGRITY & EMC EUROPE www.emc2021.org #IEEE_ESP21

Locating/reducing your own RFI sources

Always try to minimize the RFI sources at your own home

- Best way is to turn off circuit breakers in turn (watch for battery-backed devices) ٠
- Avoid buying noisy switching power supplies (QST reviews)
- Avoid (or remove) noisy LED or CFL lamps •
- Replace switching type wall warts with linear power supplies (James Electronics) ٠

Locating Sources


- Spectrum analyzer
- AM/SW radio (or portable QRP rig)
- Flag or loop antenna



2021 JOINT IEEE INTERNATIONAL SYMPOSIUM ON ELECTROMAGNETIC COMPATIBILITY, SIGNAL & POWER INTEGRITY & EMC EUROPE **#IEEE_ESP21**

www.emc2021.org

Locating/reducing your own RFI sources



ARRL RFI Page: <u>http://www.arrl.org/radio-frequency-interference-rfi</u> Example sounds of RFI, <u>http://www.arrl.org/sounds-of-rfi</u> (includes spectra)



Pre-purchase tests

Before purchasing new products:

- Examine FCC or "CE" product label (not always legit)
- Use of AM/SW radio
- Use of spectrum analyzer
- Story of my TV purchase at Best Buy



Pre-purchase tests

You can always bring in a portable spectrum analyzer!

https://www.edn.com/review-tti-psa2702t-handheld-spectrum-analyzer/ https://www.edn.com/6-ghz-spectrum-analysis-in-your-hand/



RFI detector



Tecsun PL-360 (with RSSI in dBuV)

- AM/FM/SW receivers
- Good for locating line-operated or portable RFI sources
- Can also use portable HF/VHF radios, such as Yaesu FT-817/818

https://www.edn.com/review-tecsun-pl-360-emi-receiver/



2021 JOINT IEEE INTERNATIONAL SYMPOSIUM ON ELECTROMAGNETIC COMPATIBILITY, SIGNAL & POWER INTEGRITY & EMC EUROPE
WWW.emc2021.org • #IEEE_ESP21




Grundig "Mini 400"

A "flag" antenna for locating 1.8 to 30 MHz RFI

- Resistive-terminated untuned loop
- Sharp null helps locate direction
- 2 x 4 feet in size







Flag Antenna Construction and Test Results, <u>https://www.qsl.net/wa1ion/flag/flag_antenna.htm</u> Also, available from DX Engineering as a kit and custom preamplifier, <u>https://www.dxengineering.com/parts/dxe-noiseloop</u>



Other mitigations

- Reserve operation for "quiet" areas
- SOTA / POTA (may have "noisy" neighbors, though)
- My vacation experience (S7 to S8 at home versus "S0" in Utah)
- Mobile (may deal with automobile RFI)



The future – not so rosy

- Appliance manufacturers not regulated by FCC
- Overwhelming number of cheap (unfiltered) SMPS, lighting and power supplies
- Ultimately, it may be the FAA or military that will force change, not the FCC
- Hams will need to depend on filtering and new technologies to battle RFI pollution



2021 JOINT IEEE INTERNATIONAL SYMPOSIUM ON ELECTROMAGNETIC COMPATIBILITY, SIGNAL & POWER INTEGRITY & EMC EUROPE
WWW.EMC2021.org • #IEEE_ESP21

Suggested references

- ARRL, *RFI Book* (3rd edition), 2010 (under revision as of 10/2021)
- Brown, A New Choke Cookbook for the 160-10m Bands, 2019, http://k9yc.com/2018Cookbook.pdf
- Brown, A Ham's Guide to RFI, Ferrites, Baluns, and Audio Interfacing, 2019, http://k9yc.com/RFI-Ham.pdf
- Brown, Build Contest Scores by Killing Receive Noise, 2017, <u>http://k9yc.com/KillingReceiveNoise.pdf</u>
- Example sounds of RFI, <u>http://www.arrl.org/sounds-of-rfi</u> (includes spectra)
- Fair-Rite, Can Home Solar Power and Ham Radio Coexist?, (reprint from April 2016 QST), <u>https://www.fair-rite.com/wp-content/uploads/2020/10/Brock-Fisher-April-2016-QST.pdf</u>
- KF7P Metalworks, Ferrite cores and choke kits, <u>http://www.kf7p.com</u>
- Ott, Electromagnetic Compatibility Engineering, Wiley, 2009
- PTFE insulated wire (#12), Surplus Sales of Nebraska, https://www.surplussales.com/wire-cable/wire4.html
- Silver, Grounding and Bonding for the Radio Amateur, ARRL, 2017
- Wyatt, Platform Interference Measurement and Mitigation, Interference Technology, https://interferencetechnology.com/platform-interference-measurement-mitigation/
- Wyatt, Radio Frequency Interference RFI Pocket Guide, SciTech Publishing / ARRL, 2015
- Wyatt, The EMC Blog (EDN), https://www.edn.com/electronics-blogs/4376432/The-EMC-Blog



2021 JOINT IEEE INTERNATIONAL SYMPOSIUM ON ELECTROMAGNETIC COMPATIBILITY, SIGNAL & POWER INTEGRITY & EMC EUROPE

www.emc2021.org